



3510-1 Port Jacksonville Pkwy, Jacksonville, FL 32226
800-213-7981

Instructions for Installation and Care of Honda Big Red Mini Cab Enclosure
HO-BIGRED-MC01

CAUTION: Do not smoke inside the cab or expose the product to direct flames. Product is FLAMMABLE.

Be sure to read these instructions thoroughly before opening and installing. The installation is best done when the temperature is 70 degrees F. or warmer. The temperature affects the adhesive Velcro, if conditions prevent installing in warmer weather it helps to store the adhesive Velcro at room temperature prior to installation.

1. Carefully open the carton and remove the roll the product out on a large flat surface that is clean and free of dirt. The presence of dirt may cause soiling to the textile and scratch the clear vinyl window.
2. Check over the parts included in the carton with the parts list shown below:

Velcro hook strips	2 each	18" long
Velcro hook strips	2 each	10" long
Velcro hook strips	4 each	5" long
Screw Snaps	5 each	
Mini Cab	1 each	

If any parts are damaged or missing please contact customer service at (800) 213-7981.

3. With assistance, begin by draping the enclosure over the top of the roll cage and center it. Pull the three straps sewn to the front nose down and wrap them around the front bumper as shown in the photo below. Run the straps back through the buckle but do not tighten them down yet.



4. Now move around to the rear of the cab and with the bed raised mark the locations for the four screw studs to match up with the snaps installed into the cab enclosure. Using a #2 Phillips screwdriver install the screw snaps into the plastic. TIP: You may wish to install the snaps slightly below what it looks like to ensure a tight fit, or just be sure to pull down on the cab as you mark the locations.

5. Now place the remaining Velcro to the roll cage on either side of the windshield, matching up the adhesive Velcro with the tabs sewn into the enclosure. Pull the windshield tight from side to side.
6. Then attach the 5" adhesive strips down the sides of the rear window to match up with the tabs sewn to the cab.
7. Finally, pull the straps tight on the nose to complete installation.