



# FALCON RIDGE

3510-1 Port Jacksonville Pkwy, Jacksonville, FL 32226  
800-213-7981

## **Instructions for Installation and Care of Honda Talon 4 Tinted Polycarbonate Door Panel Inserts** HO-TALON-4-DP01

Be sure to read these instructions thoroughly before opening and installing the Honda Talon 4 Polycarbonate Door Panel Inserts.

1. Check over the parts included in the cartons with the parts list shown below:

3/4" Bolts	12 each
1 1/4" Bolts	10 each
Lock Nuts	22 each
Small Washers	44 each
Long Left Angle	1 each
Long Right Angle	1 each
Short Left Angle	1 each
Short Right Angle	1 each
Door Panels	4 each

**If any parts are damaged or missing please contact customer service at (800) 213-7981.**

### **Tools Needed for Installation:**

- 1) Phillips Screwdriver
  - 2) 1/4" Drill bit and Drill
2. Begin the installation by removing the outer door skins of the Talon 4. You will see 8 Phillips head screws on the inside of the door around the edges. Remove these making sure to put them someplace they won't get lost. See Photo Below



3. Now take the door panels and the aluminum angles and bolt them together using the  $\frac{3}{4}$ " bolts, washers and lock nuts.
4. For the front panels use the long angles. You will notice that the holes on the different sides are not drilled in the same locations and the two angles are mirror images, one for the left side and one for the right side.
5. The holes that are centered are the ones used to bolt the angle to the panels. When bolting them on the holes in the other side should be offset towards the small end of the panel as shown in the photo below.



6. The rear door panels use the short angles and attach to the panels using the side with three holes with the holes of the other side of the angle towards the larger end of the panels as shown in the photo below.



7. Now shut the doors and place the panel under the door so that it fits in the space and mark the bottom of the door where to drill holes to attach it.

8. Drill holes in the bottom of the door using a ¼” drill bit or slightly larger.
9. Attach the panels to the doors using 1 ¼” bolts, washers and lock nuts. Run the bolts through the angle first so the lock nuts are on the inside of the door.
10. Finally reinstall the outer door skins and the installation is complete.

**Thank you for your purchase!**

## Return Policy

If for any reason you choose to return this product it must be returned within **30 days from date item is received**. You **MUST** package the product exactly **as it was originally packaged from the factory to get a full refund for the product!**

The vinyl windows should never be folded when packaging in the box or for storage purposes. Lay all the windows on top of each other with the canvas folded in between and the paper (if available) on both sides of the windows.

**All returned products will be inspected upon arrival at the production facility and must be in unused, factory new condition to receive refund - a 25% restocking fee will apply.**

If ordered from Falcon Ridge please call at 800-213-7981 to gain a return authorization number, use our preferred shipping carrier (UPS) to return the item (unless the item is defective, you are responsible for paying the shipping to return the item.) **Any returns submitted to Falcon Ridge without a return authorization number will be charged a 20% restocking fee.** If ordered from one of Falcon Ridge's many distributors, you must first call them and see what their return policy is. Once your item reaches our production facility, our customer satisfaction team will inspect your item to ensure unused, factory new condition. **NOTE: All windshields must be returned with the original protective film intact and not removed. Do NOT REMOVE if you have any intentions of returning the item. Refund/ replacement of a windshield will only be processed on items with original protective film or if the windshield is defective.**

Items must be properly packaged in the original shipping carton to protect them during transit and ensure your returned item arrives back factory fresh, and in new resalable condition (**any returned items that have been used, altered or damaged in any way will not be subject for a refund.**) All contents including instruction manuals, accessories, hardware, Velcro, etc. must be included in your return shipment. Only items in OEM factory new condition will be approved. Once returned items are received, credit will be issued to the original credit card/ payment method used for the purchase. Outbound shipping and return shipping cost will not be refunded. Please allow 4 to 6 weeks for your refund to be processed.

## Warranty

To The Owner of this Product:

Thank you for purchasing one of our Falcon Ridge Cab Enclosures, Tops &/or Windshields! Below are the terms under which your product is covered under our manufacturer's warranty.

30 Day Warranty which includes and is not limited to replacing the enclosure, tops and/or windshield due to defect of the product. Please refer to the return policy in this case for more information.

1 Year Warranty includes any defect in material or workmanship within this time frame we will gladly correct the problem or replace the enclosure, tops &/or windshield. Upon submitting for the correction or replacement we will need to receive pictures of the defect in material or workmanship along with the receipt from the date of purchase.